

In cases where the PPE is design to be more than six inches above the SHWT and the designer determines that a liner is not necessary, design modifications shall be incorporated to avoid dead vegetation and mosquito infestation. Those modifications include:

1. Install a liner in the forebay following the specifications of the BMP Manual.
2. Specify drought tolerant plants approved by a landscape architect following the quantity/separation requirement per the BMP Manual. We are currently working with the research team on a recommended list of plants.

If you would like for us to consider a revision for a plan approved by our office, which could benefit from the changes indicated above, please contact Jessica Batten (jbatten@ci.fay.nc.us or 433-1657) to schedule a meeting and discuss your proposal. Do not hesitate to contact me if you have any questions.